



PIMAG® PIDROGEN HYDROGEN GENERATOR

PRODUCT CODE: 13541

DESIGNED TO PROVIDE ALL THE BENEFITS OF HYDROGEN.

The PiMag® PiDrogen Hydrogen Generator transforms alkaline PiMag water into a source of highly concentrated, dissolved, natural hydrogen gas. When consumed, the water from the PiMag® PiDrogen supplies an abundance of antioxidants in order to assist in relieving oxidative stress and to help bring the body back into balance, supporting the maintenance of Active Wellness.

Hydrogen water is created when hydrogen is added to water by a process of electrolysis. The electrolyzer for the PiMag® PiDrogen Hydrogen Generator has Special Power Control Software (SPCS) technology that controls the input power and voltage, so that hydrogen-rich water can be produced continuously for each cycle.

The mini-generator is accompanied by its own 16 fl oz / 475 ml glass bottle. Because hydrogen is a natural gas, glass helps it to retain its potency for 24 hours, far longer than plastic, as well as minimizing the carbon footprint. The glass bottle allows you to drink directly from it.

- Rich source of molecular hydrogen: concentration of 800 to 1200 ppb (parts per billion)
- Exclusive programmed control system identifies hydrogenated process
- Fast cycle of six minutes with automatic shut off when ready for drinking
- Helps neutralize free radicals with antioxidants to relieve oxidative stress
- Lightweight, compact and portable

Product life is approximately two to three years (depending on use), much longer than similar products that only last three to six months and produce water mixed with ozone.

CARE INSTRUCTIONS

The PiMag PiDrogen must be cleaned properly and regularly to avoid breakdown or damage. See the PiDrogen Manual for full care instructions.

Warning: The PiMag PiDrogen Hydrogen Generator must not be immersed in water.

COMPONENTS

PIMAG PIDROGEN HYDROGEN GENERATOR: Acrylic / Plastic: JN200 - PC / Non-toxic Silicon / Electrolysis Plates: Platinum Coated Titanium.
PIMAG PIDROGEN GLASS BOTTLE: Food Grade Glass, Lead Free.

HOW TO USE:

1. Fill the bottle with PiMag water.
2. Fit the bottle to the hydrogen generator:
3. Connect the micro cable from the C connector side of the PiMag PiDrogen Hydrogen Generator and the USB side to a power charger such as: Computer, Smartphone, Powerbank, etc.
4. Wait for the 6 minute cycle to complete (The light will show blue). The flashing red light will indicate that the cycle has ended and when the red lights turns off, the hydrogen water is ready for drinking.
5. It is recommended to store the hydrogen water in the PiMag PiDrogen glass bottle and consume it within one day after preparation. The hydrogen concentration of the hydrogen water is at its maximum level for up to 4 hours and will decrease with time.
6. Recommended maximum daily use: 4 times a day.
7. Recommended consumption per day: 2 liters